




Press and hold the H7 [—] button and the remote control [⏮] button simultaneously for 5 seconds.




Press the [—] and [⏮] buttons simultaneously for 5 seconds.




Press the [○] button more than 10 times within 3 seconds until the LED color changes.



Press and hold the H7 [Wi-Fi] button for 5 seconds until the demo status LED disappears..



Press the [Power] for 10 seconds until the demo status LED disappears.



Press and hold the [Color] button for more than 10 seconds.